

### Ministerio de Obras Públicas y Transportes Dirección General de Aviación Civil

# **AIRWORTHINESS** DIRECTIVE

NUMBER: 01/93

SHEET:

1/2

AFFECTED PRODUCT

All CASA C-212 Aircraft Models.

MANUFACTURER

Construcciones Aeronaúticas,

S.A. (CASA).

ISSUE DATE

November 24, 1993. :

REFERENCE

Service Bulletin CASA nº 212-27-47, : approved later or original

revisions.

EFFECTIVE DATE

November 24 , 1993.

DESCRIPTION

to achieve A.-In order appropriate values of Rudder surface to ensure deflection required airplane flying handling qualities, regardless of the selected Rudder Assembly adjustment, Pedal modification to the pedal setting mechanism as described in 212-27-47, Service Bulletin nº original or later approved revisions thereof must be accomplished.

B.-However, from the date of reception of this Airworthiness Directive the pedal setting range established below in terms of crank turns can not be exceeded; for that procedures set forth in comunication CASA COM 212-245 must be followed.

MODEL:	CRANK TURNS:
C-212-CB	6-13
C-212-CC	6-13
C-212-CD	6-13
C-212-CE	6-13
C-212-CF	6-13



## Ministerio de Obras Públicas y Transportes Dirección General de Aviación Civil

# AIRWORTHINESS DIRECTIVE

NUMBER: 01/93

SHEET:

2/2

C-212-VA	6-13
C-212-DD	7-12
C-212-DF	4-13

Note: 1st Turn corresponds to the most forward position.

C.-In addition to the above, to get an adequate level of comfort in both pilot and copilot seats, and in the aircraft which are incorporating the IPECO Model seat, the modification relative to the pilots seat track supporting structure referenced in the Service Bulletin must be accomplished.

#### COMPLIANCE

Four months from the effective date of this Airworthiness Directive.

From the date of the reception of this Airworthiness Directive, before each flight, ensure compliance with the adjustment limitations established in paragraph B of DESCRIPTION.

### ADDITIONAL INFORMATION

For any additional information contact:

Dirección General de Aviación Civil.

Area Técnica de Certificación.

(G Garvía.)

Plaza de San Juan de la Cruz s/n 28071 Madrid

Tlf: (34 1)-597-6930 Fax: (34 1)-597-6853 Tlx: 48339 CIAL E AFTN: LEAC ZX CX.